



LiDAR Mapping Systems

LiDAR Acquisition Training Outline

Revision Date: August 26, 2020

Phoenix LiDAR Systems

2113 Wells Branch Parkway Building 1, Suite 4000
Austin, TX 78728

www.phoenixlidar.com

+1.323.577.3366

support@phoenixlidar.com

Training Outline

TABLE OF CONTENTS

Legal Notices	4
Disclaimer	4
1. Introduction	5
1.1 Training Goals	5
2. Basics of LiDAR	5
2.1 Factors Affecting Accuracy	6
3. Software Overview	6
3.1 SpatialSuite	6
3.1.1 SpatialLightHouse	6
3.1.2 SpatialExplorer	6
4. System Hardware Overview	7
4.1 Rover	7
4.1.1 Ports and User Elements	7
4.2 IMU (Inertial Measurement Unit)	7
4.3 GNSS (Global Navigation Satellite System) Receiver	7
4.4 Rover Mounting Options	7
5. Network Configuration	8
5.1 Rover Static IP Addresses	8
5.1.1 Ethernet	8
5.1.2 Wireless	8
5.2 Wired Ethernet Network Card	8
6. User Laptop Configuration	8
6.1 Install Latest NVIDIA Drivers	8
6.2 Install SpatialSuite Software	9
6.3 Modify Hosts File	9
6.4 Wired Ethernet Network Card Setup	9
7. Connect to Rover	10
7.1 Connect via Ethernet	10
7.2 Connect via Wi-Fi	10
7.2.1 Bullet Long Range Wi-Fi Module	10
7.3 Connect via Phoenix LiDAR Systems Connection Service	10
8. Reference Station	11
8.1 Hardware Overview	11
8.1.1 Stonex S900	11
8.2 Equipment Setup	11

8.3 Connection Methods	11
8.3.1 Stonex S900	11
8.3.2 Stonex S900 Downloads	12
9. SpatialExplorer	12
9.1 Acquisition - Real Time Connection	12
9.1.1 System Monitor	12
9.1.2 Sensor Controller	12
9.1.3 Commands	12
9.2 Rover Settings	13
9.2.1 General	13
9.2.2 Navigation System	13
9.2.3 LDRX	13
9.2.4 CAMX	13
10. Field Scanning	13
10.1 Reference Station Setup	13
10.1.1 Equipment Setup	13
10.2 Proper Scanning Procedure	14
10.2.1 IMU to GNSS Antenna Offsets	14
10.2.2 Static/Kinematic Alignment	14
10.2.3 Figure Eights	14
10.2.4 Activate/Deactivate Sensors	15
10.2.5 Mirror Beginning and End Procedures	15
11. Download Data	15
11.1 Rover Data	15
11.2 GNSS Reference Station Data	16
11.3 DSLR Images (optional)	16
12. Inspect Data	16
13.1 Load PLP	16
13.2 Playback Data	17

This content is subject to change.

Download the latest version from www.phoenixlidar.com.

If you have any questions about this document, please contact Phoenix LiDAR Systems by sending a message to support@phoenixlidar.com.

Copyright © 2020 Phoenix LiDAR Systems
All Rights Reserved.